

Addendum

Air Mattress Bed (Optional)

2006 Imperial™



HOLIDAY
RAMBLER®

The information printed here reflects product design, fabrication, and component parts at the date of printing. The manufacturer reserves the right, at any time, to make changes in product design or material or component specifications as its sole option, without notice. This includes the substitution of components of a different brand or trade name, which will result in comparable performance. All information printed in this document is subject to change after the date of printing. Due to product improvements, changes during the model year and/or transcription errors that may occur, information represented within the owner's manual and/or this document may not be accurate at the time of your purchase. Please confirm any information with your dealer.

The following information is an addition to the Imperial™ Owner's Manual, Section 5 - Equipment. Please utilize the information provided henceforth.

©Monaco Coach Corporation. All rights reserved. Imperial™ and Holiday Rambler® are trademarks and registered trademark of Monaco Coach Corporation. All other trademarks or registered trademarks are property of their respective holders. Brand name products of other companies mentioned in this addendum are not endorsed by Monaco Coach Corporation.

The following information is an addition to **Section 5 – Equipment** of the 2006 Imperial.

AIR MATTRESS BED (Optional)

The air mattress pump is located in the bed storage compartment and is plugged into a 120 Volt AC outlet. Two remotes are used to adjust the comfort level setting of each side of the mattress. Only one side of the mattress may be adjusted at a time.

To Operate Mattress:

Two modes can be used to adjust the comfort level of the mattress: Manual (1) mode and the Pressure Sensitive (2) mode. The air mattress detects body weight to calculate adjustments and requires someone to be on the mattress when adjusting the comfort level settings in both the Manual and Pressure Sensitive modes.

To Select Modes:

Press and hold the **MODE** button until the remote beeps, then release. The display will read **1**. Use the + and - buttons to alternate between Manual and Pressure Sensitive modes. To enter a selected mode (1 or 2), hold down the **MODE** button again until the remote beeps. To return to mode select, press and hold the **MODE** button down until the remote beeps.

Manual Mode (1):

Press and hold the + button to increase mattress pressure (firm), or press and hold the - button to decrease mattress pressure (soft). After adjusting the mattress, the current settings will be displayed on the remote for a few seconds.

Pressure Sensitive Mode (2):


The comfort level will show on the display and can be adjusted in 1% increments by pressing the + and - buttons.

To Store a Setting:

After adjusting the mattress comfort level in either Manual (1) or Pressure Sensitive (2) mode, press and hold the blue Memory button until the remote beeps. The new comfort level setting is stored. The new setting can be adjusted, then returned to the stored setting by pressing the Memory button. Holding the Memory button down until it beeps will store the current comfort level setting.

NOTE:

When adjusting comfort levels, the system uses a person's weight by sensing back pressure. Adjustments to the comfort level should only be made while lying on the mattress.



Air Mattress Remote

Instant Fill Feature:

The instant fill feature works in either the Manual or the Pressure Sensitive mode. Press the **Full** button on the remote. The mattress will inflate to 100% capacity. The instant fill works with or without someone on the mattress.

Cleaning and Maintenance:

- Check air filter at back of pump monthly. Rinse with water to clean and let dry before reinstalling.
- Over time normal settling and impressions in the cover will occur. Only the cover quilting is affected. Steam clean only. Allow the mattress cover to dry thoroughly. Do not dry clean.

Troubleshooting


Slow Leak:

Check fittings on front of pump and connections to mattress. If the hose leaks from the outlet side of pump, remove clamp, cut hose 1" and re-install hose and hose clamp.

If problem continues, cut hose from air pump nozzle and install hose plugs (located in the mattress cover) in hose ends. If air holds in the mattress, the problem may be the pump. If air does not hold, then the problem is most likely the mattress. Call *Comfortaire* at **1-800-759-0594**.

Pump will not operate:

- The motorhome must have the generator running, the inverter engaged or be hooked to shore power for the mattress pump to operate. Ensure the pump in the bed storage compartment is plugged in.
- Check the fuse on the pump. Use a key or a small screwdriver to open the fuse compartment and inspect the rearward fuse. Replace it with the spare located in the holder if necessary. When the fuse holder is pushed in, the fuse is installed.
- If the motorhome has power but the remote does not display, check line connections at remotes and at the pump.



031117b

Pump operates but pressure does not change:

Check for kinks in the hose or a visible obstruction between the pump and mattress.

NOTE:

DO NOT disassemble pump. Internal components can be damaged and warranty will be voided.



MONACO®

Monaco Coach Corporation

91320 Coburg Industrial Way

Coburg, OR 97408

800-634-0855

www.monacocoach.com

Warranty/Technical Support

Toll Free 877-466-6226



**HOLIDAY
RAMBLER®**