

Security System

2008

Dynasty[®], The Executive[®],
Imperial[™] & Marquis[®]



The information printed here reflects product design, fabrication, and component parts at the date of printing. The manufacturer reserves the right, at any time, to make changes in product design or material or component specifications as its sole option, without notice. This includes the substitution of components of a different brand or trade name, which will result in comparable performance. All information printed in this document is subject to change after the date of printing. Due to product improvements, changes during the model year and/or transcription errors that may occur, information represented within the owner's manual and/or this document may not be accurate at the time of your purchase. Please confirm any information with your dealer.

The following information supercedes previous information and applies to certain model motorhomes equipped with a Roadmaster Chassis.

©Monaco Coach Corporation. All rights reserved. All other trademarks or registered trademarks are property of their respective holders. Brand name products of other companies mentioned in this addendum are not endorsed by Monaco Coach Corporation.

The following information supersedes the information printed in the 2008 Dynasty, Executive, Imperial and Marquis Owner's Manuals, on page 50, under the "Security System" heading, concerning arming and disarming the security system.

SECURITY SYSTEM

Arming & Disarming the Security System

NOTE:

Monaco Coach Corporation does not warrant or guarantee against damage caused by break-in or theft of the motorhome, in part or in whole, or against the loss or damage to the contents thereof in which a security system is installed. The security system is only a deterrent against possible break in or theft.

To Arm the System:

The system can be armed and disarmed with the key fob or the key pad on the entry door grab handle.

- ◆ Exit the motorhome and close all protected entrances. This includes the entry door, bedroom windows and all bay doors with pin switches.

With Key Fob:


- ◆ Press the "Lock" button on the key fob twice. This requires two hard pushes with a distinct pause in between. The system will beep one time and the dash-mounted LED will flash every two seconds when the system is armed.

With Key Pad:


- ◆ Press and hold the "Lock" button on the key pad (button #1 with lock symbol) for approximately two seconds until the entry door and bay doors lock. Release the Lock button. Within five seconds, press and hold the Lock button again for approximately two seconds. The system will beep one time and the dash-mounted LED will flash every two seconds when the system is armed.

To Disarm the System:

- ◆ Press the "Unlock" button on the key fob, or enter the unlock code on the key pad, to disarm the security system. The dash-mounted LED will turn off and the system will beep twice when disarmed.



Security System Key Fob



Key pad located on entry door grab handle.

Monaco Coach Corporation
91320 Coburg Industrial Way
Coburg, OR 97408
800-634-0855
www.monaco-online.com

Warranty/Technical Support
Toll Free 877-466-6226